

Hardware Manual

LTE Industrial Connectivity Gateway ICR-1645




Advantech Czech s.r.o., Sokolska 71, 562 04 Usti nad Orlici, Czech Republic Document No. MAN-0091-EN, revised on April 23, 2025.

© 2025 Advantech Czech s.r.o. No part of this publication may be reproduced or transmitted in any form or by any means, electronic or mechanical, including photography, recording, or any information storage and retrieval system without written consent. Information in this manual is subject to change without notice, and it does not represent a commitment on the part of Advantech.

Advantech Czech s.r.o. shall not be liable for incidental or consequential damages resulting from the furnishing, performance, or use of this manual.

All brand names used in this manual are the registered trademarks of their respective owners. The use of trademarks or other designations in this publication is for reference purposes only and does not constitute an endorsement by the trademark holder.

Used symbols



Contents

1.	Product Overview	1		
	1.1Product Introduction1.2Usage Examples1.3Hardware Overview1.4Order Codes1.5Package Contents1.6Product Dimensions1.7Mounting Recommendations1.8Wall Mounting1.9DIN Rail Mounting1.10Product Label1.11First Use	6 9 10 13 14 15 16		
2.	Hardware Functionality	18		
	 2.1 SIM Card Slots 2.2 Antennas Interfaces 2.3 Ethernet Interfaces 2.4 Power Supply 2.5 DIN & DOUT Interfaces 2.6 Serial Interfaces 2.7 LED Status Indication 2.8 Reset Functions 	19 20 21 22 23		
3.	Technical Parameters	25		
	3.1Basic Parameters .3.2Standards and Regulations .3.3Type Tests and Environmental Conditions .3.4Parameters of Cellular Module for ICR-16xx-EU .3.5Parameters of Cellular Module for ICR-16xx-CN .3.6Parameters of GNSS (for ICR-16xxG only) .3.7Parameters of WiFi (for ICR-16xxW only) .3.8Parameters of I/O Ports .3.9Parameters of Serial Interfaces .3.10System Configuration .	26 27 28 29 30 31		
Ap	opendix A: Troubleshooting	34		
Ар	opendix B: Customer Support	37		
Ар	opendix C: Regulatory & Safety Information	38		
Ap	Appendix D: Related Documents 39			

List of Figures

1	Cellular Internet Access
2	Backup for Internet Access
3	VPN Networks Interconnection
4	Serial Gateway
5	Router Hardware Overview – Front View
6	Router Hardware Overview – Rear View
7	Router Dimensions – Front, Top and Right view for basic set
8	Router Dimensions – Front, Top and Right view with Wall Mounting holder
9	Router Dimensions – Front, Top and Right view with DIN holder
10	Wall Mounting Clip
11	Default Position of the DIN Rail Clip 15
12	Product Label
13	SIM Cards Insertion
14	Ethernet Connector Pinout of RJ45 Socket 19
15	Power Connector Pinout
16	Position of the Grounding Screw 20
17	I/O Connector Pinout
18	Functional Scheme of the Digital Interface
19	Serial Connector Pinout
20	Resetting the Router

List of Tables

1	Router Hardware Overview – Front View
2	Router Hardware Overview – Rear View
3	Order Codes Overview
4	Contents of Package
5	Ethernet Connector Pinout Description of RJ45 Socket
6	Power connector pinout
7	I/O Ports Pinout
8	Connection of RS232
9	Connection of RS485
10	LED Status Indication
11	LED Status Indication
12	Basic Parameters
13	Standards and Regulations
14	Type Tests and Environmental Conditions
15	Technical Parameters of Cellular Module
16	Technical Parameters of Cellular Module
17	Technical Parameters of GNSS
18	Technical Parameters of WiFi
19	Electrical Characteristics of Digital Input 32
20	Parameters of Serial Interfaces
21	System Configuration

1. Product Overview

1.1 Product Introduction

The ICR-1645 series industrial connectivity gateway is designed for wireless communication, connecting IP devices and serial buses to cellular networks. It is ideal for M2M and IoT applications such as kiosks, industrial PCs, HMIs, traffic controllers, meters, UPS systems, and more. The LTE Cat.4 peak downlink data rate is around 150 Mbps, with an uplink peak data rate of 50 Mbps.

The ICR-1645 router features five Fast Ethernet ports (1x WAN + 4x LAN) and optional digital I/O (1x DI, 1x DO) and Serial (1x RS232 + 1x RS485) connectivity. Optional WiFi 5 or GNSS can be included. The gateway supports **VPN** tunnel creation with various protocols for secure communications and provides diagnostic functions, including automatic monitoring and restart of connections, and a hardware watchdog to monitor router status.

Based on the ICR-OS operating system, the gateway's open Linux platform allows for extensive programming of customer software applications in **Python, C/C++**. It supports uploading of certain Router Apps to extend firmware functionalities, with a free app library available for customers to enhance specific router functionalities.

Compatibility with Advantech's **remote device management** platform, *WebAccess/DMP*, offers extensive device management and monitoring, ensuring that devices remain up-to-date and secure.

1.2 Usage Examples

Cellular Internet Access

- This example demonstrates a common scenario where the cellular router facilitates access from a local LAN to the Internet via the cellular network.
- This functionality is not available on LAN routers lacking a cellular interface.




Figure 1: Cellular Internet Access

Backup for Internet Access

- This example showcases how a cellular router's Internet access can be backed up.
- Backup options include PPPoE connections, Ethernet wired connections or WiFi.




Figure 2: Backup for Internet Access

VPN Networks Interconnection

- This example highlights the establishment of a secure VPN tunnel for interconnecting the configured Advantech router with a router in a remote network, facilitated via the Internet.
- The configured router connects to the Internet using the cellular network.




Figure 3: VPN Networks Interconnection

Serial Gateway

- This example depicts a scenario where the configured Advantech router grants access to a PLC device interfaced serially with the router.
- The PLC device, accessible over the entire Internet network, can be controlled from a remote local network, such as one running a SCADA system.
- This functionality is exclusive to routers equipped with a serial interface.




Figure 4: Serial Gateway

1.3 Hardware Overview

In this chapter, all components of the router case are described, including links to chapters that provide more details.



Figure 5: Router Hardware Overview - Front View

#	Item/Caption	Туре	Description
1	RST	_	Button to reboot the router or restore default settings; see Chapter 2.8.
2	LEDs	—	Status LED indicators; see Chapter 2.7.
3	GND Screw	M3	Ensure proper grounding; refer to Chapter 2.4.
4	PWR	2-pin terminal	Power supply socket; see Chapter 2.4.
5	Serial & I/O	10-p term.	1 RS232, 1 RS485, 1 digital input, and 1 digital output interfaces. See Chapter 2.6 for serial interface details, Chapter 3.8 for I/O parameters, and Chapter 3.9 for serial interface parameters.
6	ETH0, ETH1	RJ45	1 Gb Ethernet LAN interfaces; see Chapter 2.3.
7	DIN Clip	—	DIN mounting clip, not included as standard accessories, can be ordered optionally; see Chapter 1.9.

Table 1: Router Hardware Overview – Front View




Figure 6: Router Hardware Overview - Rear View

#	Item/Caption	Туре	Description
8	Wall Clip	—	Wall mounting clip, included as standard accessories; see Chapter 1.8.
9	SIM Slots	Micro SIM	Two Micro SIM card slots; details in Chapter 2.1.
10	ANT, AUX and DIV	_	Connectors for both the main and diversity antennas of the cellular module. Refer to Chapter 2.2 for details, Chapter 3.4 & 3.5 for cellular module parameters.

Table 2: Router Hardware Overview - Rear View

1.4 Order Codes

Order codes overview is shown in the table below.

Order code	Configuration
ICR-1645-EU-A	LTE Connectivity Gateway with 5 x Gigabit Ethernet ports and 1xRS232+1xRS485+1xDI+1xDO ports for EMEA , certified with CE/UKCA.
ICR-1645W-EU-A	LTE Connectivity Gateway with 5 x Gigabit Ethernet ports and 1xRS232+1xRS485+1xDI+1xDO ports, WiFi for EMEA , certified with CE/UKCA.
ICR-1645G-EU-A ¹	LTE Connectivity Gateway with 5 x Gigabit Ethernet ports and 1xRS232+1xRS485+1xDI+1xDO ports, GNSS for EMEA , certified with CE/UKCA.
ICR-1645-CN-A	LTE Connectivity Gateway with 5 x Gigabit Ethernet ports and 1xRS232+1xRS485+1xDI+1xDO ports for China .
ICR-1645W-CN-A	LTE Connectivity Gateway with 5 x Gigabit Ethernet ports and 1xRS232+1xRS485+1xDI+1xDO ports, WiFi for China .
ICR-1645G-CN-A ¹	LTE Connectivity Gateway with 5 x Gigabit Ethernet ports and 1xRS232+1xRS485+1xDI+1xDO ports, GNSS for China .

Table 3: Order Codes Overview

¹Availability may vary. Please consult your local sales representative for more information.

1.5 Package Contents

The standard set of the router includes the following items, as listed in the table below:

ltem#	Description	Figure	Q'ty
1	Router		1 pc
2	Wall Mount Kit (packed in accessory box, including 4 screws of type M3 x 5L)		1 pc
3	2-pin terminal block for power supply (installed on the router)		1 pc
4	10-pin terminal block for Serial and IO (installed on the router)		1 pc
5	LTE Antennas (packed in accessory box)		2 pc
6	WiFi Antenna (packed in accessory box, WiFi model only)		1 pc
7	Printed Quick Start Guide Leaflet		1 pc

Table 4: Contents of Package

1.6 Product Dimensions

For the dimensions of the router see the figures below. Note that all sizes are measured in millimeters.

Basic Set




Figure 7: Router Dimensions - Front, Top and Right view for basic set

Variant with Wall Mounting Clip




Figure 8: Router Dimensions - Front, Top and Right view with Wall Mounting holder

Variant with DIN Rail Clip




Figure 9: Router Dimensions - Front, Top and Right view with DIN holder

1.7 Mounting Recommendations

The router can be placed in the following ways:

• On a flat surface.

1

- On a wall using the wall mounting clip (refer to Chapter 1.8).
- On a DIN rail EN 60715 with the metal DIN rail clip (refer to Chapter 1.9).

For most applications involving a built-in router within a switchboard, two types of environments are typically encountered:

- A non-public industrial environment with low voltage but high interference.
- A public environment with low voltage and without high interference.

For both of these environments, it's feasible to mount the router to a switchboard, eliminating the need for immunity examination or EMC-related issues as per EN 61439-1:2011 standards.

To comply with the EN 61439-1:2011 specification, follow these assembly instructions when attaching a router to a switchboard:

- When using whip antennas, maintain a minimum distance of 6 cm from cables and metal surfaces on all sides to avoid interference. If an external antenna is used apart from the switchboard, a lightning conductor is necessary.
- When mounting a router on sheet steel, consider using a cable antenna.

For all cables, it's recommended to bundle them, following these guidelines:

- The combined length of the cable bundle (power supply and data cables) should not exceed 1.5 m. If data cable length surpasses 1.5 m or if the cable runs toward the switchboard, installing surge protectors is advisable.
- Data cables must not be bundled with mains voltage cables (230 V/50 Hz or 120 V/60 Hz).
- Ensure sufficient space is left between each connector for cable handling.
- For proper router functionality, use an earth-bonding distribution frame to ground the grounding screw (refer to Chapter 2.4).

1

1.8 Wall Mounting

The wall mounting clip is included as a standard accessory (packed in the accessory box, including 4 screws of type M3 x 5L).

The router can be affixed to a wall or another surface using the wall mounting clip. The delivered wall mounting clip can be assembled to the router as shown in Figure 10.

The wall mounting clip features two holes with a diameter of 4.5 millimeters for screw placement. For precise mounting dimensions, refer to Figure 8 in Chapter 1.6.

When attaching the wall mounting clip, tighten the screws with a maximum torque of 0.6 Nm (6 kg.cm).



Figure 10: Wall Mounting Clip

1.9 DIN Rail Mounting

The DIN rail mounting clip is not included as a standard accessory; it can be ordered separately under P/N OPT1-DIN-ICR1X-00.

You can attach the DIN rail clip to the router for mounting it onto a DIN rail that complies with the 60715 standards. The default position of the clip is depicted in Figure 11. If necessary, the clip can also be rotated into all four positions.

When attaching the clip, use 4 screws of type M3 x 5L, and tighten the screws with a maximum torque of 0.6 Nm (6 kg.cm).




Figure 11: Default Position of the DIN Rail Clip

1.10 Product Label

The figure below shows an example of the product labels with all the information printed on them.



Figure 12: Product Label

1.11 First Use

You can perform the initial configuration of the router using a web browser on your PC. This interface enables router monitoring, configuration, and administration.

- Before putting the router into operation, ensure that all components required for running your applications are connected. Refer to Chapter *1.3 Hardware Overview* for an overview of the hardware.
- Do not operate the router without an antenna connected to the main antenna connector. Transmitted energy will be reflected by an open connector, which could potentially damage the equipment.

The procedure for connecting to a new router is described in the *Configuration Manual* [1], Chapter *Introduction* \rightarrow *Configuration Environments* \rightarrow *Initial Web Configuration GUI Access*. This manual also provides detailed descriptions and examples of router configuration using the web interface.

2. Hardware Functionality

See Chapter 1.3 for an overview of the product's hardware, along with links to chapters offering detailed explanations.

2.1 SIM Card Slots

Slots for two SIM cards are located on the router beneath a metal cover. If you plan to use this device for cellular network communication, insert an activated data-provisioned SIM card into the SIM card slot.


You have the option to install two SIM cards simultaneously for utilizing the switching feature. The SIM cards can have different Access Point Names (APNs) configured. The procedure for changing SIM cards is outlined below. If the SIM requires a PIN, input it in the router's web interface (*Administration* \rightarrow *Unlock SIM Card*).

Type of SIM card: Micro SIM (3FF) 15.0 \times 12.0 \times 0.76 mm.

Inserting the SIM card:

- Always disconnect the router from the power supply before handling the SIM card.
- Unscrew the two screws on the SIM card cover and remove the cover.
- To remove an inserted SIM card, use the flat end of a spudger or your fingernail to press the SIM card slightly into its slot until you hear a click. Upon hearing the click, release the card, and it will pop out of its slot.
- To insert a SIM card, push the card into the slot until it clicks into place.
- Put the cover back and secure it with the two screws.





2.2 Antennas Interfaces

The ANT and DIV SMA female connectors are intended for connecting the main and diversity cellular antennas to the router.

Additionally, SMA/RP-SMA¹ female connectors labeled *AUX* are provided for connecting GNSS/WiFi antennas on models that support WiFi or GNSS.

Do not run the router without connected cellular antennas as the energy from the transmission is effectively reflected by the open end and can damage the equipment.

Recommended tightening moment for screwing the antenna to the SMA connector is 0.9 Nm.

2.3 Ethernet Interfaces

The RJ45 panel socket is used for four ETH0 and one ETH1 Ethernet interfaces. The pinout of the socket is shown in Figure 14 and described in Table 5.




Figure 14: Ethernet Connector Pinout of RJ45 Socket

Pin	10base-T & 100base-T	1000base-T
1	Tx+ (Transmit Data+)	BI_DA+ (BiDirectional pair A+)
2	Tx- (Transmit Data-)	BI_DA- (BiDirectional pair A-)
3	Rx+ (Receive Data+)	BI_DB+ (BiDirectional pair B+)
4	—	BI_DC+ (BiDirectional pair C+)
5	—	BI_DC- (BiDirectional pair C-)
6	Rx- (Receive Data-)	BI_DB- (BiDirectional pair B-)
7	—	BI_DD+ (BiDirectional pair D+)
8	—	BI_DD- (BiDirectional pair D-)

Table 5: Ethernet Connector Pinout Description of RJ45 Socket

The isolation barrier of the Ethernet ports against the ground is 1500 V.

⁰SMA female for GNSS, RP-SMA female for WiFi

2.4 Power Supply

1

A two-pin terminal connector (pitch 3.5 mm) is utilized to power the router. The corresponding connector is included as a standard accessory with the router.

Pin	Signal mark	Description
1	VCC(+)	Positive pole of DC supply voltage (+9 to +48 V DC)
2	GND(-)	Negative pole of DC supply voltage

Table 6: Power connector pinout




Figure 15: Power Connector Pinout

The required power supply voltage for the router ranges between +9 V and +48 V DC. Refer to the connection scheme in Figure 15 for proper setup. The router is equipped with built-in protection against reversed polarity, functioning without signaling. To guarantee correct operation, the power source must be capable of providing a sufficient amount of energy, as detailed in the consumption section of Chapter 3.1.

Grounding the router using the grounding screw eliminates the protection against reversed polarity. Ensure the negative pole of the DC power supply shares the same voltage reference as the grounding screw. A voltage difference between these points may damage the router, necessitating repairs exclusively by an authorized service center.

Unit has to be supplied by a power supply specified as a Limited Power Source (LPS) or CEC/NEC Class 2 source of supply.

All metal parts, including the box, are interconnected with the negative pole of the power supply (common pole). If recommended for the installation environment, protect the router by properly grounding it using the grounding screw, as depicted in Figure 16. The maximum tightening torque for the grounding screw is 0.6 Nm (6 kg.cm).



Figure 16: Position of the Grounding Screw

2.5 DIN & DOUT Interfaces

The pins of I/O interface are physically connected to the 10-pin terminal block panel socket. The pinout of the I/O interface is described in Figure 17 and Table 7.




Figure 17: I/O Connector Pinout

Pin	Signal mark	Description
3	BIN	Digital input
4	BOUT	Digital output
5,10	GND	Ground (common negative pole)

Table 7: I/O Ports Pinout

The I/O interface is not electrically isolated from the router.

The I/O user interface is designed for digital input processing and digital output control. For detailed electrical parameters see Chapter 3.8. The functional scheme of connection for the digital input and digital output is in Figure 18.




Figure 18: Functional Scheme of the Digital Interface

2.6 Serial Interfaces

Two independent serial interfaces are connected to the 10-pin terminal block panel socket.




Figure 19: Serial Connector Pinout

The RS232 interface can be configured on the web GUI by navigating to Configuration \rightarrow Expansion Port 1. For the pinout, refer to Table 8. .

Pin	Signal mark	Description
6	TXD	OUT
7	RXD	IN
8	RTS	OUT
9	CTS	IN
10	GND	GROUND

Table 8: Connection of RS232

The RS485 interface can be configured on the web GUI by navigating to Configuration \rightarrow Expansion Port 2. For the pinout, refer to Table 9.

Pin	Signal mark	Description
1	D (+)	IN/OUT
2	D (-)	IN/OUT
5	GND	GROUND

Table 9: Connection of RS485



The serial interfaces are not eletrically isolated from the router.

2.7 LED Status Indication

There are status LEDs on the top side of the router to provide router status information. Moreover, ETH0 and ETH1 connectors, located on the front panel, have two additional LEDs providing information about the port status.

	Caption	Color	State	Description
ባ	PWR	Green Green Off	On Blinking Off	Powered up, the system is booting up. System is ready and operating normally. No power.
utl	SIG	Green Orange Red Off	On / blinking On / blinking On / blinking Off	Good cellular signal. Fair cellular signal. Poor cellular signal. No cellular link.
1	SIM	Green Orange Green Orange Red Off	Blinking Blinking On On Fast blinking Off	SIM 1 is selected, waits for data connection. SIM 2 is selected, waits for data connection. Connects through SIM 1. Connects through SIM 2. Missing SIM card or PIN code problem. No SIM card is selected.
ጺ	USR	Green	—	The function of this LED is user-defined.
	ETH0 ETH1	Green Green	On Off	Selected 1 Gbps bit rate. Selected 100/10 Mbps bit rate.
	ETH0 ETH1	Yellow Yellow Yellow	On Brief off blinks Off	The network cable is connected. Data transmission. The network cable is not connected.

Table 10: LED Status Indication

The following describes when USR is defined as Serial or WiFi:

	Caption	Color	State	Description
ጺ	Serial/USR	Green Off	Blinking Off	Serial Port 1 TX/RX transmitting data. No RS232/RS485 data.
ጺ	WiFi/USR	Green Green Off	On Blinking Off	AP or STA mode is selected. Transmitting data. No AP or STA mode is selected.

Table 11: LE	ED Status	Indication
--------------	-----------	------------

2.8 Reset Functions

The *RST* button has multiple functions. For more details, refer to the configuration manual [1], Chapter *Introduction* \rightarrow *Device* \rightarrow *Reset*.

Use a narrow screwdriver or a small tool to press the *RST* button.



Figure 20: Resetting the Router

3. Technical Parameters

3.1 Basic Parameters

Parameter		Description
Temperature range	Operating Storage	-30 °C to +75 °C (-22 °F to +167 °F) -40 °C to +85 °C (-40 °F to +185 °F)
Humidity	Operating Storage	5 to 95 % relative humidity non condensing 5 to 95 % relative humidity non condensing
Altitude	Operating	2000 m/70 kPa
Degree of protection		IP30
Supply voltage		9 – 48 V DC
Consumption for non-WiFi / WiFi version	Idle Average Maximum	2.7 W / 3.6 W 3.7 W / 4.8 W 5.5 W / 6.8 W
Dimensions of device ((w/o clips)	$116\times39\times113.5\text{mm}$ (4.56" \times 1.53" \times 4.47")
DIN rail clip specification	on	DIN 30 mm (DIN clip is an optional)
Weight		ICR-16XX: 470 g (1.04 lbs) (excl. accessories below) LTE Antenna: 25.2 g (0.06 lbs) Wall-mount bracket: 50 g (0.11 lbs) WiFi Antenna 7.8 g (0.02 lbs)

Table 12: Basic Parameters

3.2 Standards and Regulations

Parameter	Description
Radio	EN 301 908-1, EN 301 908-2, EN 301 908-13, EN 301 908-25,EN 303 413, EN 300 328, EN 301 893
EMC	EN 301 491-1, EN 301 489-17, EN 301 489-19, EN 301 489-52, EN 610000-6-2, EN 610000-6-3, EN 55032, EN 61000-4-2, EN 61000-4-3, EN 61000-4-4, EN 61000-4-5, EN 61000-4-6
Safety	EN 62368-1
Mechanical	EN 60529, EN 60068-2-27, EN 60068-2-64
Climatic	EN 60068-2-1, EN 60068-2-2, EN 60068-2-14, EN 60068-2-78
National	CE, UKCA for ICR-16xx-EU SRRC, NAL for ICR-16xx-CN
Environmental	REACH, RoHS3 and WEEE compliant
	Table 13: Standards and Regulations

3.3 Type Tests and Environmental Conditions

Phenomena	Test	Description	Test levels
ESD	EN 61000-4-2	Enclosure contact	\pm 6 kV (crit. A)
RF field AM modulated	EN 61000-4-3	Enclosure	20 V/m (crit. A) (80 – 1000 MHz) 10 V/m (crit. A) (1 – 6 GHz)
Fast transient	EN 61000-4-4	Signal ports Power ports Ethernet ports	$\begin{array}{l} \pm \ 1 \ \text{kV} \ (\text{crit. A}) \\ \pm \ 2 \ \text{kV} \ (\text{crit. A}) \\ \pm \ 1 \ \text{kV} \ (\text{crit. A}) \end{array}$
Surge	EN 61000-4-5	Ethernet ports Power ports	\pm 1 kV (crit. A), shielded cab. \pm 1 kV (crit. A)
RF conducted	EN 61000-4-6	All ports	10 V/m (crit. A) (0.15 – 80 MHz)
Radiated emis- sion	EN 55032	Enclosure	Class B
Conducted emission	EN 55032	Signal ports Power ports Ethernet ports	Class B Class B Class B
Dry heat	EN 60068-2-2	Test Bb, storage +8	5 °C, operation +75 °C
Cold	EN 60068-2-1	Test Ab, storage -40)°C, operation -40°C
Damp heat	EN 60068-2-78	95% rel. humidity (-	+40 °C)
Dry heat, cyclic	EN 60068-2-30	+55 $^{\circ}$ C / +25 $^{\circ}$ C, rel.	. humidity 95 %, 12 h - 12 h
Dry heat	EN 60068-2-2	Test Bb, storage +85 °C, operation +75 °C	
Thermal shock/ temp. variation	EN 60068-2-14	Test Nb, -30 °C/+75	°C, 3h/3h, 2 cycles, 3 K/min
Degrees of pro- tection provided by enclosures	EN 60529	IP30	
Vibration, broad- band random	EN 60068-2-64	Spectrum A.3 cat 1,	breakpoints A.6 cat 1
Shock	EN 60068-2-27	50 m/s ² , 11 ms, half	sine, 10 in each dir.

Table 14: Type Tests and Environmental Conditions

3.4 Parameters of Cellular Module for ICR-16xx-EU

Parameter	Description
Antenna	 Connector type: SMA (ANT + DIV) VSWR: ≤ 3 Efficiency: > 30%
LTE parameters	 Support up to non-CA Cat.4 FDD and TDD Supported modulations: QPSK (DL/UL), 16QAM and 64QAM Supported FDD bands: B1 (2100), B3 (1800+), B5 (850), B7 (2600), B8 (900 GSM), B20 (800 DD) Supported TDD bands: B38 (TD 2600), B40 (TD 2300), B41 (120M) (TD 2500+) Bandwidth: 1.4 MHz to 20 MHz Peak bit rates: 300 Mbps (DL), 50 Mbps (UL) @ 2 × 2 MIMO Power class: Class 3 (23 dBm ± 2 dBm)
WCDMA parameters	 Support 3GPP R8/DC-HSDPA/HSPA+/HSDPA/HSUPA/WCDMA Supported modulations: QPSK, 16QAM and 64QAM Supported bands: B1 (2100 MHz), B5 (850 MHz), B8 (900 MHz) Peak bit rates: 42 Mbps (DL), 5.76 Mbps (UL) Power class: Class 3 (23.5 dBm ± 2 dBm)

Table 15: Technical Parameters of Cellular Module

3.5 Parameters of Cellular Module for ICR-16xx-CN

Parameter	Description
Antenna	 Connector type: SMA (ANT + DIV) VSWR: ≤ 3 Efficiency: > 30%
LTE parameters	 Support up to non-CA Cat.4 FDD and TDD Supported modulations: QPSK (DL/UL), 16QAM and 64QAM Supported FDD bands: B1 (2100), B3 (1800+), B5 (850), B8 (900 GSM) Supported TDD bands: B34 (TD 2100), B38 (TD 2600), B39 (TD 1900), B40 (TD 2300), B41 (120M) (TD 2500+) Bandwidth: 1.4 MHz to 20 MHz Peak bit rates: 300 Mbps (DL), 50 Mbps (UL) @ 2 × 2 MIMO Power class: Class 3 (23 dBm ± 2 dBm)
WCDMA parameters	 Support 3GPP R8/DC-HSDPA/HSPA+/HSDPA/HSUPA/WCDMA Supported modulations: QPSK, 16QAM and 64QAM Supported bands: B1 (2100 MHz), B8 (900 MHz) Peak bit rates: 42 Mbps (DL), 5.76 Mbps (UL) Power class: Class 3 (23.5 dBm ± 2 dBm)

Table 16: Technical Parameters of Cellular Module

3.6 Parameters of GNSS (for ICR-16xxG only)

Parameter	Description
GNSS Systems	GPS, Galileo, QZSS, GLONASS, and BDS
Antenna	Connector type: SMA Input impedance: 50Ω Supports active or passive antenna
Features	Protocol: NEMA 0183
Frequency	GPS: 1575.42±1.023 MHz Galileo: 1575.42±2.046 MHz QZSS: 1575.42 MHz GLONASS: 1597.5–1605.8 MHz BDS: 1561.098±2.046 MHz
Sensitivity (autonomous)	Acquisition: -146 dBm Reacquisition: -157 dBm Tracking: -157 dBm
Acquisition time (autonomous)	Cold start: 35.0 s Warm start: 26.0 s Hot start: 2.5 s
Accuracy	2.5 m
	Table 17: Technical Parameters of GNSS

3.7 Parameters of WiFi (for ICR-16xxW only)

Parameter	Description
Antenna Connectors	R-SMA - 50 Ω
Supports WiFi bands	2.400 – 2.4835 GHz 5.150 – 5.850 GHz
Standards	IEEE: 802.11b, 802.11b/g, 802.11b/g/n, 802.11a, 802.11an, 802.11ac
2.4 GHz supported channels	1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13
5 GHz supported channels	36, 40, 44, 48, 149, 153, 157, 161, 165
Type of Device	Access point (AP) Station (STA)
Security – Standards	WPA, WPA2, WPA3, 802.1X
Security – Encryption	WEP, TKIP, AES
AP maximum users	Access Point mode: up to 16 clients max

Table 18: Technical Parameters of WiFi

3.8 Parameters of I/O Ports

Electrical characteristics of the digital input are in Table 19. Status of the digital input can be retrieved in the router's web interface (on the *General Status* page) or by the status ports and io get commands, see *Command Line Interface* application note.

Logical ¹	Status ²
1	Open
0	Short to ISO_GND

Table 19: Electrical Characteristics of Digital Input

The maximum digital output load is 500 mA at 48 V.

3.9 Parameters of Serial Interfaces

Supported parameters of the RS232 and RS485 interfaces, which can be configured on Web GUI in *Configuration* \rightarrow *Expansion Port 1* resp. *Configuration* \rightarrow *Expansion Port 2* menu items, are in Table 20.

Parameter	Description
Baudrate	300, 600, 1200, 2400, 4800, 9600, 19200, 38400, 57600, 115200.
Data Bits	5, 6, 7, 8.
Parity	none, even, odd.
Stop Bits	1, 2.
Flow Control	none, CTS/RTS

Table 20: Parameters of Serial Interfaces

¹The digital status returned by the <u>io get</u> shell command.

²The digital status returned by the status ports shell command and displayed on the *General Status* page.

3.10 System Configuration

The main parametes of the system are listed in Table 21.

Parameter	Description
CPU architecture	ARM Cortex-A7
CPU frequency	1.2 GHz
CPU power	1.9 DMIPS/MHz
Flash memory	512 MB of eMMC • \approx 60.5 MB for Router Apps • \approx 26.7 MB for customer data
RAM size	256 MB
Watchdog	Yes

Table 21: System Configuration

Appendix A: Troubleshooting

If you cannot connect to the router from your PC, your network card may be configured in such a way that it is not possible to connect to the router. Take one or more of the following steps in order to solve the problem:

- Make sure your PC's network card is configured to obtain the IP address form the DHCP server (by default the DHCP server is running in the router).
- Connect the router to the PC via Switch.
- Connect the router to the PC, start the router first and then start the PC after the router's initialization.

Ethernet connection fails or is not establishing.

• It is possible to turn auto negotiation off and set a rate and duplex manually on the Ethernet interface of the router. Available on "LAN Configuration" page in the router.

Mobile WAN connection fails.

- Check the signal power ("Mobile WAN status" page). If the signal power is weak, you will have to use a better antenna. If the neighbouring cells have a similar signal strength, you will need to use a directional antenna. For proper operation, the signal levels have to be good.
- Try to enable automatic ping from the router, which will check the connection when there are no data running and in the case of a failed ping, restart the connection. This can be done on the "Mobile WAN Configuration" page in the router in the "Check connection" section. "Enable + bind" option is to ensure the ping goes always through Mobile WAN network interface.

Mobile WAN connection cannot be established.

- Check the "Mobile WAN Configuration" APN, name, password and IP address (all can be blank).
- Try to enter the SIM card PIN verify that the SIM card has the PIN code entered. Available on "Unlock SIM Card" page in the "Administration" section.
- In a private APN it is not recommended to get the DNS settings from operator (on "Mobile WAN" page)
- Go to "System Log" page in "Status" section and observe where the error occurs.

I cannot connect from the Internet to the device behind the router. I have NAT enabled.

• The device's gateway has to be configured so it points to the router.

I can't access my Web server placed behind the router over NAT.

• The remote HTTP access to the router has to be disabled on "NAT Configuration" page in the router. Also enable "Send all remaining incoming packets to default server" feature and fill in the IP address of your Web server. On the Web server, the default gateway has to be the IP address of the router.

DynDNS doesn't work.

• With private APN this will not work.

- If the same IP address is recorded in your canonic name as a dynamically assigned address, it means that the operator is using NAT or a firewall.
- You can verify NAT using ping to your server with static address and then compare with router's IP address.
- You can verify a Firewall by accessing remotely to the router's Web interface.
- The operator may not provide the address of DNS server and without DNS server's address it is impossible to connect to the dyndns.org server. The following messages will be shown in the System Log:
 - DynDNS daemon started
 - Error resolving hostname: no such file or directory
 - Connect to DynDNS server failed

L2TP or IPSec isn't establishing.

- Check the "System Log" page for error messages.
- IPSec tunnel establishes but the communication does not run.
 - Probably there are bad routing rules defined in the connected devices, or the default gateway.
- I switched the router to offline mode by SMS message, but the router is in online mode after reboot.
 - SMS messages do not change the router configuration. They remain in effect only until the router is rebooted.

La Serial communication is not working.

• Verify that the router model supports serial communications. Also verify the serial communication settings. To do so, open the router's configuration menu via the web browser, select the appropriate "Expansion Port" from "Configuration" part of the menu and verify the settings.

Is the router Cisco compatible? Can I use the Cisco configuration?

• No, the Firmware in the router (ICR-OS) is based on Linux with BusyBox. Thus the Cisco configuration cannot be used. But network connections are defined by standards so connecting the router to the Cisco or other networking devices is possible and will be compatible.

FTP or SFTP does not work

FTP will work on v2 routers only. You can use SFTP on all routers to transfer files to/from the
router. If having troubles with FTP on v2 routers, make sure you have FTP enabled: "Configuration" section, "Services", "FTP". Then you can connect with any client on port 21 with name
and password same as for the Web interface. If having troubles with SFTP, make sure you have
SSH enabled: "Configuration" section, "Services", "SSH". Then you can connect with any client
on port 22 with name and password same as for the Web interface.

How can I connect to the router's command line? (SSH, Telnet)

• You can use SSH on all routers or Telnet on v2 routers only. SSH is enabled by default, but you can verify in Web interface in "Configuration" section, "Services", "SSH". Then connect with any SSH client on port 22 of the router. User and password is the same as for the Web interface. Telnet on v2 routers can be enabled here: "Configuration" section, "Services", "Telnet".

Appendix B: Customer Support

Customer Support for Europe

Advantech Czech s.r.o.

Sokolska 71 562 04, Usti nad Orlici Czech Republic

Phone:+353 91 792444Fax:+353 91 792445E-mail:iiotcustomerservice@advantech.euWeb:www.advantech.com

Customer Support for NAM

Advantech B+B SmartWorx

707 Dayton Road Ottawa, IL 61350 USA

Phone:+1-800-346-3119 (Monday - Friday, 7 a.m. to 5:30 p.m. CST)Fax:+1-815-433-5109E-mail:support.iiot.ana@advantech.comWeb:www.advantech.com

Customer Support for Asia

 Phone:
 +886-2-2792-7818 #1299 (Monday – Friday, 9 a.m. to 5:30 p.m. UTC+8)

 Fax:
 +886-2-2794-7327

 E-mail:
 icg.support@advantech.com.tw

 Web:
 www.advantech.com

Appendix C: Regulatory & Safety Information

Safety Notices

Please, observe the following instructions:

- The router must adhere to all relevant international and national laws, including any specific restrictions governing its use in designated applications and environments.
- To prevent potential injury and appliance damage, ensure compliance with regulations by using only authorized accessories. Unauthorized modifications or use of unapproved accessories could damage the router, violate regulations, and void the warranty.
- · Do not attempt to open the router.
- Before handling the SIM card, turn off the router and disconnect it from the power supply.
- **Caution!** This equipment is not suitable for use in areas with children. Small children could swallow the SIM card.
- Ensure the power supply does not exceed 48 V DC maximum.
- Avoid exposing the router to extreme ambient conditions. Safeguard it against dust, moisture, and high temperatures.
- Only deploy routers with appropriate certification and labeling in environments containing flammable or explosive materials, such as gas stations, chemical plants, or areas involving explosives. Users must observe restrictions pertaining to radio device usage in such settings.
- When traveling by plane, switch off the router. Using it onboard could jeopardize flight operations, disrupt mobile networks, and potentially violate regulations. Non-compliance may result in telephone service suspension, cancellation, or legal repercussions.
- Exercise heightened caution when operating the router near personal medical devices like cardiac pacemakers or hearing aids.
- The router may cause interference when operated in close proximity to TV sets, radio receivers, or personal computers.
- It's advisable to create a suitable backup of all critical settings stored in the device's memory.

Product Disposal Instructions

The WEEE (Waste Electrical and Electronic Equipment: 2012/19/EU) directive was introduced to ensure that electrical/electronic products are recycled using the best available recovery techniques to minimize the environmental impact. This product contains high quality materials and components which can be recycled. At the end of it's life this pro- duct MUST NOT be mixed with other commercial waste for disposal. The device contains a battery. Remove the battery from the device before disposal. The battery in the device needs to be disposed of apart accordingly. Check the terms and conditions of your supplier for disposal information.



Appendix D: Related Documents

[1] ICR-1600 Configuration Manual



(€ UK CA

We, Advantech Czech s.r.o., declare that the radio equipment narrated in this user's manual complies with Directive **2014/53/EU**.

We, Advantech Czech s.r.o., declare that the radio equipment narrated in this user's manual complies with Radio Equipment Regulations 2017 (**S.I. 2017 No. 1206**).

The full text of the EU Declaration of Conformity is available at the following internet address: icr.advantech.com/doc