


# ADVANTECH



## Modbus to MQTT



© 2025 Advantech Czech s.r.o. No part of this publication may be reproduced or transmitted in any form or by any means, electronic or mechanical, including photography, recording, or any information storage and retrieval system without written consent. Information in this manual is subject to change without notice, and it does not represent a commitment on the part of Advantech.

Advantech Czech s.r.o. shall not be liable for incidental or consequential damages resulting from the furnishing, performance, or use of this manual.

All brand names used in this manual are the registered trademarks of their respective owners. The use of trademarks or other designations in this publication is for reference purposes only and does not constitute an endorsement by the trademark holder.

# Used symbols



## Important

**Important** — Indicates a risk to personal safety or potential damage to the router. Follow these instructions precisely to prevent injury or equipment damage.



## Warning

**Warning** — Highlights conditions that may cause malfunction, loss of data, or unexpected behavior in specific situations. Read carefully before proceeding.



## Info

**Info** — Provides helpful tips, context, or references that improve understanding but are not strictly required to complete the task.



## Code Example



Code Example - Copy-pasteable configuration snippets or CLI commands.

# Contents

<b>1. Router App Description</b>	<b>1</b>
1.1 Modbus To MQTT . . . . .	1
1.2 Web Interface . . . . .	1
<b>2. Configuration</b>	<b>2</b>
2.1 Settings . . . . .	2
2.2 CSV config file . . . . .	4
<b>3. Status</b>	<b>7</b>
3.1 Log . . . . .	7
3.2 Mapping table . . . . .	7
3.3 MQTT Data Format . . . . .	8
<b>4. Related Documents</b>	<b>9</b>

# List of Figures

1 Menu . . . . .	1
2 Settings — Part 1 . . . . .	2
3 Settings — Part 2 . . . . .	3
4 CSV file . . . . .	4
5 CVS file import . . . . .	6
6 Mapping table . . . . .	7

# List of Tables

1 Settings Example Items Description . . . . .	2
2 Configuration items description . . . . .	4

# 1. Router App Description

## Warning

- This Router App is not included in the standard router firmware. Instructions for uploading this Router App can be found in the Configuration Manual (see Chapter [Related Documents](#)).
- This Router App is compatible only with firmware version 6.4.x

## 1.1 Modbus To MQTT

*Modbus to MQTT* is a Router App designed to facilitate seamless communication between Modbus/TCP devices and an MQTT broker. It operates as a Modbus/TCP master to interact with Modbus/TCP devices and as an MQTT publisher/subscriber to communicate with an MQTT broker.

## 1.2 Web Interface

After installing the module, its GUI can be accessed by selecting the module name on the *Router Apps* page within the router's web interface.

The left side of this GUI includes a menu with *Status*, *Configuration*, and *Customization* sections. The *Status* section features *Log* and *Mapping Table* items, while the *Configuration* section includes a *Settings* item. The *Customization* section contains a *Return* item, which allows users to switch back from the module's web interface to the router's main web configuration pages. The main menu of the module's GUI is illustrated in Figure 1.

Status
Log
Mapping Table
Configuration
Settings
Customization
Return

Figure 1: Menu

## 2. Configuration

### 2.1 Settings

Configuration for this Router App can be carried out on the *Settings* page, which is located under the *Configuration* menu section. Details of all configuration items available on the *Settings* page are illustrated in the figure and described in the table below.

**Modbus to MQTT Settings**

**Modbus to MQTT**

Service Enable	OFF	Enable the Modbus to MQTT.
Log Enable	OFF	Enable the Service Log.
Broker Address	127.0.0.1	The remote Broker Server Address.
Broker Server Port	1883	The Broker Server Port Number ( 1 - 65535 ).
MQTT Keepalive	60	
MQTT QoS	0	
MQTT Retain	OFF	
Client ID		
MQTT Anonymous	Disable	
Azure SAS-token generation	Disable	
MQTT Username		
MQTT Password		
MQTT TLS	Disable	
Timeout	1000 msec	The Modbus TCP Timeout.
CSV config		
	Upload CSV config file	Download CSV config file
CA certificate		
	Upload CA certificate file	
Local Certificate		
	Upload Local certificate file	
Local Private Key		
	Upload Local Private Key file	

Figure 2: Settings — Part 1

Item	Description
Service Enable	Enabled, Modbus to MQTT APN functionality of the module is turned on.
Log Enable APN	Enable the Service Log.
Broker Address	Enter the remote Broker Server Address.
Broker Server Port	Enter Broker Server Port Number (1-65535).
MQTT Keepalive	Enter MQTT keepalive interval (1-3600).
MQTT QoS	Enter MQTT QoS value (0,1,2).
MQTT Retain	Enable for message retaining.
Client ID	Enter Client ID.
MQTT Anonymous	Enable MQTT Anonymous
MQTT Username	Enter MQTT Username.
MQTT Password	Enter MQTT Password.

Table 1: Settings Example Items Description

Item	Description
MQTT TLS	Enable MQTT TLS.
Interval(ms)	Enter Modbus TCP Polling Interval.
Timeout(ms)	Enter Modbus TCP Timeout.
CSV Config	Upload the file containing your CSV config here.
CA Certificate	Upload your CA Certificate here.
Local Certificate	Upload your Local Certificate here.
Local Private Key	Upload your Local Private Key here.

Table 1: (continued)

The second part of the MQTT settings involves configuring the MQTT Payload. The payload is the actual content carried by an MQTT message, which can include various types of data such as sensor readings, status updates, commands, or other pertinent information required by the MQTT application.

The data within the payload can be encoded in various formats, tailored to meet the specific needs of the application utilizing MQTT.

For this setup, the payload includes predefined variables: **Topic**, **Name**, **Value**, **Time**, **IP**, **Port**, **ID**, **FC**, **Address**, and **Data Length**. Additionally, there is provision for ten custom fields that can be configured as needed.

MQTT Payload Settings			
Name	Enable	Field Name	
Topic	<input type="checkbox"/> Enable	<input type="text" value="topic"/>	
Name	<input type="checkbox"/> Enable	<input type="text" value="name"/>	
Value	<input type="checkbox"/> Enable	<input type="text" value="value"/>	
Time	<input type="checkbox"/> Enable	<input type="text" value="time"/>	
IP	<input type="checkbox"/> Enable	<input type="text" value="ip"/>	
Port	<input type="checkbox"/> Enable	<input type="text" value="port"/>	
ID	<input type="checkbox"/> Enable	<input type="text" value="id"/>	
FC	<input type="checkbox"/> Enable	<input type="text" value="fc"/>	
Address	<input type="checkbox"/> Enable	<input type="text" value="address"/>	
Data Length	<input type="checkbox"/> Enable	<input type="text" value="data_length"/>	
Extend MQTT Payload Settings			
Name	Enable	Field Name	
Custom1 Field	<input type="checkbox"/> Disable	<input type="text" value="custom1_field"/>	CSV Config Field : Q.
Custom2 Field	<input type="checkbox"/> Disable	<input type="text" value="custom2_field"/>	CSV Config Field : R.
Custom3 Field	<input type="checkbox"/> Disable	<input type="text" value="custom3_field"/>	CSV Config Field : U.
Custom4 Field	<input type="checkbox"/> Disable	<input type="text" value="custom4_field"/>	CSV Config Field : V.
Custom5 Field	<input type="checkbox"/> Disable	<input type="text" value="custom5_field"/>	CSV Config Field : W.
Custom6 Field	<input type="checkbox"/> Disable	<input type="text" value="custom6_field"/>	CSV Config Field : X.
Custom7 Field	<input type="checkbox"/> Disable	<input type="text" value="custom7_field"/>	CSV Config Field : Y.
Custom8 Field	<input type="checkbox"/> Disable	<input type="text" value="custom8_field"/>	CSV Config Field : Z.
Custom9 Field	<input type="checkbox"/> Disable	<input type="text" value="custom9_field"/>	CSV Config Field : AA.
Custom10 Field	<input type="checkbox"/> Disable	<input type="text" value="custom10_field"/>	CSV Config Field : AB.

Figure 3: Settings — Part 2

## 2.2 CSV config file

In Modbus to MQTT, user configures the mapping between Modbus/TCP and MQTT through CSV file. In the csv file, the field separator (delimiter) is a comma.

Topic	Name	IP	Port	Device ID	Function Code	Address	Data length	Modbus Data type	Data Swap	Byte Swap
env1-DI	DI_01	192.168.1.15	502	1	2	1	1	Boolean	None	False
env1-DO	DO	192.168.1.15	502	1	1	1	1	Boolean	None	False
env1-Temp	Temperature	192.168.1.15	502	1	4	1	2	Float	None	False
env1-Mode	Mode	192.168.1.15	502	1	3	10	2	Unsigned Integer	None	False
env1-Mode-w	Mode	192.168.1.15	502	1	16	10	2	Unsigned Integer	None	False
env2-DI	DI_01	192.168.1.16	502	1	2	1	1	Boolean	None	False
env2-DO	DO	192.168.1.16	502	1	1	1	1	Boolean	None	False
env2-Temp	Temperature	192.168.1.16	502	1	4	1	2	Float	None	False
env2-Mode	Mode	192.168.1.16	502	1	3	10	2	Unsigned Integer	None	False
env2-Mode-w	Mode	192.168.1.16	502	1	16	10	2	Unsigned Integer	None	False

MQTT Data Type	Multiplier	Offset	Polling Interval (ms)	Send When Change	Custom Field	custom2 field	Send Group	Send Interval
Boolean	1	0	10000	No		0	0	0
Boolean	1	0	10000	No		0	0	0
Float	1	0	10000	Yes		0	0	0
Unsigned Integer	1	0	10000	No		0	0	0
Unsigned Integer	1	0	10000	No		0	0	0
Boolean	1	0	10000	No		0	0	0
Boolean	1	0	10000	No		0	0	0
Float	1	0	10000	Yes		0	0	0
Unsigned Integer	1	0	10000	No		0	0	0
Unsigned Integer	1	0	10000	No		0	0	0

Figure 4: CSV file

Item	Description
Topic	MQTT topic
Name	The name to identify the mapping.
IP	The Modbus device IP address.
Port	The TCP port number of the remote Modbus slave device.
Device ID	The Modbus/TCP slave ID.
Function Code	Modbus Function Code (FC). In Modbus to MQTT, supported function codes are: 1, 2, 3, 4, 5, 6, 15, 16 <b>01</b> : Read coils; <b>02</b> : Read discrete inputs; <b>03</b> : Read holding registers; <b>04</b> : Read input register; <b>05</b> : Write single coil; <b>06</b> : Write single register; <b>15</b> : Write multiple coils; <b>16</b> : Write multiple registers.
Address	Designate the read from/write to starting address for the Modbus registry.
Data length	When FC=1, 2, 5 or 15, the unit is bit(s) When FC=3, 4, 6 or 16, the unit is word(s)

Table 2: Configuration items description



Item	Description
Modbus Data type	Modbus data type. Options: Boolean, Integer, Unsigned Integer, Float
Data Swap	The Data Swap field determines the order in which the particular bytes of the received/transmitted data are delivered. <b>None:</b> Do not swap; <b>Word:</b> 0x01, 0x02 becomes 0x02, 0x01; <b>Double Word:</b> 0x01, 0x02, 0x03, 0x04 becomes 0x04, 0x03, 0x02, 0x01. <b>Double Word - Frame:</b> 0x01, 0x02, 0x03, 0x04 becomes 0x04, 0x03, 0x02, 0x01. <b>Quad Word:</b> 0x01, 0x02, 0x03, 0x04, 0x05, 0x06, 0x07980 becomes 0x07980, 0x05, 0x06, 0x03, 0x04, 0x01, 0x02.
Byte Swap	Option: True, False When option is True: 0x01, 0x02 becomes 0x01, 0x02. 0x01, 0x02, 0x03, 0x04 becomes 0x01, 0x02, 0x03, 0x04.
MQTT Data type	MQTT data type. Options: Boolean, Integer, Unsigned Integer, Float, Long Integer, Unsigned Long Integer
Multiplier	The value used to multiply the data value.
Offset	The value used to add/subtract the data value.
Polling Interval (ms)	Modbus Polling Interval, unit: milliseconds. The value range: 1 10000000
Send When Change	Select that the data is sent immediately when change happens on modbus slave. Options: Yes, No
Custom Field	Custom definition value
Custom2 Field	Custom definition value
Send Group	Set group number for MQTT multiple messages to one message. The value range is from 0 to 500. When the value is 0, this feature is disabled.
Send Interval	Send MQTT message interval for the group in seconds. The value range is from 1 to 10000 seconds.

Table 2: (continued)

The CSV file can be imported into the Advantech router on the settings page of the relevant Router App. After importing the file and clicking the **Save** button, the new mapping configuration takes effect immediately.

Modbus to MQTT Settings		
Modbus to MQTT		
Service Enable	OFF	Enable the Modbus to MQTT.
Log Enable	OFF	Enable the Service Log.
Broker Address	127.0.0.1	The remote Broker Server Address.
Broker Server Port	1883	The Broker Server Port Number ( 1 - 65535 ).
MQTT Keepalive	60	
MQTT QoS	0	
MQTT Retain	OFF	
Client ID		
MQTT Anonymous	Disable	
Azure SAS-token generation	Disable	
MQTT Username		
MQTT Password		
MQTT TLS	Disable	
Timeout	1000 msec	The Modbus TCP Timeout.
CSV config	env2,DI2,192.168.88.231,502,1,2,1,1,Boolean,None,FALSE,Boolean,1,0,10000,No,0	
CA certificate		
Local Certificate		
Local Private Key		

Figure 5: CVS file import

## CSV Example

Copy-pastable example from the section above:

```
env1-DI,DI_01,192.168.1.15,502,1,2,1,1,Boolean,None,FALSE,Boolean,1,0,10000,No,0,0,0,1
env1-DO,DO,192.168.1.15,502,1,1,1,1,Boolean,None,FALSE,Boolean,1,0,10000,No,0,0,0,1
env1-Temp,Temperature,192.168.1.15,502,1,4,1,2,Float,None,FALSE,Float,1,0,10000,Yes,0,0,0,1
env1-Mode,Mode,192.168.1.15,502,1,3,10,2,Unsigned Integer,None,FALSE,Unsigned Integer,1,0,10000,No,0,0,0,1
env1-Mode-w,Mode,192.168.1.15,502,1,16,10,2,Unsigned Integer,None,FALSE,Unsigned Integer,1,0,10000,No,0,0,0,1
env2-DI,DI_01,192.168.1.16,502,1,2,1,1,Boolean,None,FALSE,Boolean,1,0,10000,No,0,0,0,1
env2-DO,DO,192.168.1.16,502,1,1,1,1,Boolean,None,FALSE,Boolean,1,0,10000,No,0,0,0,1
env2-Temp,Temperature,192.168.1.16,502,1,4,1,2,Float,None,FALSE,Float,1,0,10000,Yes,0,0,0,1
env2-Mode,Mode,192.168.1.16,502,1,3,10,2,Unsigned Integer,None,FALSE,Unsigned Integer,1,0,10000,No,0,0,0,1
env2-Mode-w,Mode,192.168.1.15,502,1,16,10,2,Unsigned Integer,None,FALSE,Unsigned Integer,1,0,10000,No,0,0,0,1
```

# 3. Status

## 3.1 Log

Log messages from the Router App will be displayed in this section.

## 3.2 Mapping table

The Modbus/TCP to MQTT mapping will be shown in Mapping Table WEB page.

Status

Log

Mapping Table

Configuration

Settings

Customization

Return

Modbus to MQTT Settings

Topic	Name	Modbus IP-Port	Modbus Slave ID	Modbus Function Code	Modbus Address	Modbus Data Length	Modbus Data Type	MQTT Data Type	Data Swap	Byte Swap	Multiplier	Offset	Polling Interval	Send When Change	Send Group	Send Interval
env1-DI	DI_01	192.168.1.15	1	2	1	1	Boolean	Boolean	None	False	1.000000	0.000000	10000	No	0	1
env1-DO	DO	192.168.1.15	1	1	1	1	Boolean	Boolean	None	False	1.000000	0.000000	10000	No	0	1
env1-Temp	Temperature	192.168.1.15	1	4	1	2	Float	Float	None	False	1.000000	0.000000	10000	Yes	0	1
env1-Mode	Mode	192.168.1.15	1	3	10	2	Unsigned-Int	Unsigned-Int	None	False	1.000000	0.000000	10000	No	0	1
env1-Mode-w	Mode	192.168.1.15	1	16	10	2	Unsigned-Int	Unsigned-Int	None	False	1.000000	0.000000	10000	No	0	1
env2-DI	DI_01	192.168.1.16	1	2	1	1	Boolean	Boolean	None	False	1.000000	0.000000	10000	No	0	1
env2-DO	DO	192.168.1.16	1	1	1	1	Boolean	Boolean	None	False	1.000000	0.000000	10000	No	0	1
env2-Temp	Temperature	192.168.1.16	1	4	1	2	Float	Float	None	False	1.000000	0.000000	10000	Yes	0	1
env2-Mode	Mode	192.168.1.16	1	3	10	2	Unsigned-Int	Unsigned-Int	None	False	1.000000	0.000000	10000	No	0	1
env2-Mode-w	Mode	192.168.1.15	1	16	10	2	Unsigned-Int	Unsigned-Int	None	False	1.000000	0.000000	10000	No	0	1
		0	0	0	0	0	Boolean	Boolean	None	False	0.000000	0.000000	0	No	0	0
		0	0	0	0	0	Boolean	Boolean	None	False	0.000000	0.000000	0	No	0	0

Custom Field Mapping Table

Name	Field 1	Field 2	Field 3	Field 4	Field 5	Field 6	Field 7	Field 8	Field 9	Field 10
DI_01	0	0	0x0E							
DO	0	0								
Temperature	0	0								
Mode	0	0								
Mode	0	0								
DI_01	0	0								
DO	0	0								
Temperature	0	0								
Mode	0	0								
Mode	0	0								

Figure 6: Mapping table

### 3.3 MQTT Data Format

When Modbus/TCP FC is 1, 2, 3 or 4, Modbus to MQTT will work as MQTT publisher to post Modbus/TCP data in JSON format to MQTT broker. When Modbus/TCP FC is 5, 6, 15 or 16, Modbus to MQTT will work as MQTT subscriber to ask subscription information, and forward the data to Modbus/TCP device. Here are the example of MQTT data that is published from Modbus to MQTT.

#### Code Example



```
"time" : "2020-06-09 15:25:06.667",  
"topic" : "env1-DI"  
"name" : "DI_01",  
"value" : true,  
"ip" : "192.168.1.15",  
"port" : "502",  
"id" : "1",  
"fc" : "1",  
"address" : "1",  
"data length" : "1"
```

Note that Modbus to MQTT verify just topic, name and value fields of the received subscription information.

#### Code Example



```
"topic": "env1-Mode-w",  
"name": "Mode",  
"value": "1234"
```

## 4. Related Documents

You can obtain product-related documents on *Engineering Portal* at [icr.advantech.com](http://icr.advantech.com) address.

To get your router's *Quick Start Guide*, *User Manual*, *Configuration Manual*, or *Firmware* go to the [Router Models](#) page, find the required model, and switch to the *Manuals* or *Firmware* tab, respectively.

The *Router Apps* installation packages and manuals are available on the [Router Apps](#) page.

For the *Development Documents*, go to the [Development](#) page.