

ADVANTECH



Band Select



© 2025 Advantech Czech s.r.o. No part of this publication may be reproduced or transmitted in any form or by any means, electronic or mechanical, including photography, recording, or any information storage and retrieval system without written consent. Information in this manual is subject to change without notice, and it does not represent a commitment on the part of Advantech.

Advantech Czech s.r.o. shall not be liable for incidental or consequential damages resulting from the furnishing, performance, or use of this manual.

All brand names used in this manual are the registered trademarks of their respective owners. The use of trademarks or other designations in this publication is for reference purposes only and does not constitute an endorsement by the trademark holder.

Used symbols



Danger – Information regarding user safety or potential damage to the router.



Attention – Problems that can arise in specific situations.



Information – Useful tips or information of special interest.

Contents

1. Description of Router App	1
1.1 Web Interface	2
1.2 Examples for a Few Cellular Modules	3
2. Related Documents	5

List of Figures

1	RA Menu for a Two Cellular Module Router	2
2	Configuration Form for Module PLS8-E	3
3	Configuration Form for Module EC25AU	3
4	Configuration Form for Module MC8705	4

List of Tables

1. Description of Router App



Please use this router app with caution and observe the legal restrictions.



This router app is not installed on *Advantech* routers by default. Uploading of this router app is described in the Configuration Manual (see Chapter [Related Documents](#)).

Please note that this router app is intended only for routers with following cellular modules:

- **Cinterion**
 - PHS8-E
 - PHS8-P
 - PLS8-E
 - PLS8-X
 - PLS83-EP
 - PLS83-W
 - PLS83-X
- **Sierra Wireless**
 - MC7304
 - MC7710
 - MC8705
- **Cellient**
 - MPL200
- **Telit**
 - LE910-EU V2
 - LE910-NA1
 - FN990A28
- **Quectel**
 - BG95-M3
 - BG96
 - EC25-AU
 - EC25-AF
 - EC25-E
 - EC25-EU
 - EC25-EUX
 - EC25-J

- EM12-G
- RM505Q-AE
- RM520N-GL
- **Huawei**
 - ME909s-120
 - ME909s-821
- **SIMCom**
 - SIM7070
- **Unitac**
 - ML620EU
 - ML620DE
- **Fibocom**
 - FM101-EAU

Type of the cellular module installed in the router can be found in the *Mobile WAN* status in the *Mobile Network Information* part.

Band Select module allows user to adjust the portfolio of frequency bands which router supports. What are frequency bands? Frequency bands are groupings of radio frequencies that are used by mobile networks to communicate. For example for cellular network in Europe are used frequency bands 900 MHz and 1800 MHz. For cellular network in USA is mainly used frequency band 1900 MHz. So for a router to work properly in USA as well as in Europe, it would need to support the 1900 MHz band and one or both of the 900 MHz or 1800 MHz bands used in Europe.

1.1 Web Interface

The web interface available for configuration of the *Band Select* router app can be invoked by pressing the module name on the *Router apps* page of the router's web interface. The left part of the web interface (i.e. menu) contains only the *Return* item, to switch back to the router's web interface. In case of routers with two cellular modules, there are *Modul 1* and *Modul 2* items available to manage both cellular modules of the router separately.




Figure 1: RA Menu for a Two Cellular Module Router

The actual configuration of the *Band Select* router app is performed via the form on the right of the web interface. The possible configuration is displayed according to the cellular module installed in the router. To keep the bands limited, router app must be installed and enabled. Choose the desired frequency bands for the module, select *Enable Band Select* and then confirm with the *Send* button.

1.2 Examples for a Few Cellular Modules

Band select

Customization	Band select !!use carefully!!
Information Module 1 Return	<input type="checkbox"/> Enable Band select
	Module 1 type: PLS83-EP
	GSM <input checked="" type="checkbox"/> GSM-850 (850 MHz) <input checked="" type="checkbox"/> GSM-900 (900 MHz) <input checked="" type="checkbox"/> GSM-1800 (1800 MHz) <input checked="" type="checkbox"/> GSM-1900 (1900 MHz)
	UMTS <input checked="" type="checkbox"/> B1 (2100 MHz) <input checked="" type="checkbox"/> B3 (1800 MHz) <input checked="" type="checkbox"/> B8 (900 MHz)
	LTE <input checked="" type="checkbox"/> B1 (2100 MHz) <input checked="" type="checkbox"/> B3 (1800 MHz) <input checked="" type="checkbox"/> B5 (850 MHz) <input checked="" type="checkbox"/> B7 (2600 MHz) <input checked="" type="checkbox"/> B8 (900 MHz) <input checked="" type="checkbox"/> B20 (800 MHz) <input checked="" type="checkbox"/> B28 (700 MHz)
	<input type="button" value="Send"/>

Figure 2: Configuration Form for Module PLS8-E

Band select

Customization	Band select !!use carefully!!
Information Module 1 Return	<input checked="" type="checkbox"/> Enable Band select
	Module 1 type: EC25-AU
	GSM <input checked="" type="checkbox"/> GSM-850 (850 MHz) <input checked="" type="checkbox"/> GSM-900 (900 MHz) <input checked="" type="checkbox"/> GSM-1800 (1800 MHz) <input checked="" type="checkbox"/> GSM-1900 (1900 MHz)
	UMTS <input checked="" type="checkbox"/> B1 (2100 MHz) <input checked="" type="checkbox"/> B2 (1900 MHz) <input checked="" type="checkbox"/> B5 (850 MHz) <input checked="" type="checkbox"/> B8 (900 MHz)
	LTE <input checked="" type="checkbox"/> B1 (2100 MHz) <input checked="" type="checkbox"/> B2 (1900 MHz) <input checked="" type="checkbox"/> B3 (1800 MHz) <input checked="" type="checkbox"/> B4 (2132 MHz) <input checked="" type="checkbox"/> B5 (850 MHz) <input checked="" type="checkbox"/> B7 (2600 MHz) <input checked="" type="checkbox"/> B8 (900 MHz) <input checked="" type="checkbox"/> B28 (700 MHz) <input checked="" type="checkbox"/> B40 (2300 MHz)
	<input type="button" value="Send"/>

Figure 3: Configuration Form for Module EC25AU

Band select

Customization	Band select !!use carefully!!
Information Module 1 Return	<input type="checkbox"/> Enable Band select
	Module type: MC8705
	All bands <input checked="" type="radio"/>
	GSM 900/1800 <input type="radio"/>
	GSM All <input type="radio"/>
	WCDMA All <input type="radio"/>
	WCDMA 900/2100 <input type="radio"/>
	<input type="button" value="Send"/>

Figure 4: Configuration Form for Module MC8705

2. Related Documents

You can obtain product-related documents on *Engineering Portal* at icr.advantech.com address.

To get your router's *Quick Start Guide*, *User Manual*, *Configuration Manual*, or *Firmware* go to the [Router Models](#) page, find the required model, and switch to the *Manuals* or *Firmware* tab, respectively.

The *Router Apps* installation packages and manuals are available on the [Router Apps](#) page.

For the *Development Documents*, go to the [Development](#) page.